Offline Use | Instant Local Setup — No App or Wi-Fi needed!

NEEWER

3. White Noise & Lights

- Press to turn lighting/music on or off.
- Press / to select white-noise sounds .
- Rotate / dial to adjust the sound level.
- Press to cycle RGB colors.
- Press to adjust color temperature.
- Rotate / dial to adjust light brightness.
- During playback, Press to set music & light auto-off countdown.

Tip: Long press the button to completely shut off the center LCD display and indicator lights.



4. Bluetooth Speaker Connection

Turn on Then searching and pairing "NEEWER NF03" on your phone's Bluetooth list.

Tip：If it fails to reconnect automatically, tap "NEEWER NF03" in the Bluetooth list to reconnect.

1. Set Date & Time

- Long-press button for 2S, the numbers will flash.
- Rotate / dial to adjust numbers;
- Press button to confirm, Then set each digit one by one.

Tip: Date and time will be automatically synced when connected to the APP.

2. Set Alarm

- Long-press button for 2S, the numbers will flash.
- Rotate / dial to adjust numbers;
- Press button to confirm, Then set each digit one by one.

Tip: Short press to turn the active alarm ON or OFF.

Privacy: Only sync device settings. No personal data collected or shared.


Pairing Guide

Download NEEWER Home App (Android / iOS)→Register account & log in→Tap "+" on App top-right, follow prompts to add device.

Android iOS

Tip: Device supports 2.4GHz Wi-Fi only; 5GHz Wi-Fi unsupported. Confirm password has no special characters. Control via phone Bluetooth if Wi-Fi is unavailable or fails.

Setup Guide



FAQ

Q: Does the sunrise light wake me like real sunlight?
A: It emits soft light for slow wake-up in dim rooms. Bright surroundings reduce its effect and it cannot match natural sunlight. Pair with alarm tone for better results.

Q: Why low volume & weak bass?
A: Rear speaker optimized for white noise/ nature sounds. Built for soothing sleep audio, not heavy bass or high-volume party use.

Q: How to switch between °F and °C?
A: Connect the device to the Neewer Home App, then switch the temperature unit in general settings.

Q: How to turn off the alarm?
A: Short-press button to stop alarm. Long-press to disable snooze. Tap device button to fully cancel it, and the icon will disappear.